



F121 Softbox Assembly Instructions

(F121 Models: INT902, INT903, INT906, INT907 & INT950)

Contents:

- Metal S-Type speedring = 1
- Black metal rods = 4
- Black softbox outer material shell = 1
- Small white inner diffuser = 1
- Large white outer diffuser = 1

Instructions:

1. Unfold the black softbox outer material onto a table top
2. Insert the metal speedring in the gap (centre) of the black softbox material. Position the speedring so the narrowest diameter face (rotating part) is on top of the table. This is the end you will affix to the actual F121 head.
3. The first installation of the rectangular F121 Softbox is a little tight as the fabric hasn't been stretched.
4. Place the fat bulbous end of the metal rod in the metal speedring holes and the thinner end in the softbox fabric pockets in each corner.
5. The rods should be inserted in the following holes of the speedring: C1, C2, C3 & C4
6. Work on the diagonals first (C1 & C3 then C2 & C4)
7. You may have to force the rods into the softbox fabric pockets. The rods will flex which is normal.
8. It may take a bit of force to set up the softbox.
9. Once set up, then readjust and fasten all the four velcro straps around the speedring
10. Clip in the small white inner diffuser onto the four elastic straps half way up the internal sides
11. Add the outer diffuser fitting the material into each corner and then aligning the velcro strips in the centre of each side.
12. Attach to your F121 head. Happy shooting!